





Elderhorst Bells, Inc.

STANDARD CLOCK DIAL STYLES


PAGE 1




EB-302




EB-303




EB-303NR




EB-305




EB-306




EB-306R




EB-307




EB-308




EB-309




EB-309M




EB-309H




EB-311




EB-312



EB-312V



EB-313




EB-314




Elderhorst Bells, Inc.

STANDARD CLOCK DIAL STYLES


PAGE 2



EB-314R




EB-315




EB-316




EB-316V




EB-316R



EB-316MR



EB-320




EB-320M




EB-321




EB-321V




EB-322




EB-323




EB-323R



EB-325



EB-326




EB-328




Elderhorst Bells, Inc.

STANDARD CLOCK DIAL STYLES


PAGE 3




EB-328V




EB-333




EB-333R




EB-334




EB-334V




EB-335D




EB-335DV




EB-336




EB-336V



EB-337




EB-337V



EB-346




EB-347



EB-348


OPTIONAL RINGS




EB-R1



EB-R2



EB-R3



EB-R4



Elderhorst Bells, Inc.

STANDARD CLOCK HANDS

PAGE 1




EB-401



EB-402




EB-403



EB-404



EB-405



EB-405T



EB-406




EB-407



EB-408



EB-409



EB-410



EB-412




Elderhorst Bells, Inc.

STANDARD CLOCK HANDS


PAGE 2




EB-412-H




EB-413



EB-414



EB-415



EB-416




EB-417




EB-418



EB-418-H



EB-419



EB-420